



Installation Instructions for OleeGuard Impact Resistant Panels

Climate Acclimation

Acclimate the material and adhesive in the environmentally controlled area where it will be installed 24 hours before installation. The area requires a temp between 65 and 80 degrees F and a humidity level less than 80%. (Minimum of 68 degrees if using Spray-Lock adhesive.) Take care to maintain a constant temperature and humidity level for 24 hours before install, during the entire install, and 48 hours after install. (For Spray-Lock adhesive, HVAC must be operated for a min of 72 hours at 68 degrees prior to installation.)

Surface Prep

Surfaces must be free from dust, grease, sealants, foreign matter and loose paint. Remove any coatings designed to improve clean-up. If using XT2000 adhesive, primer may be required. See the specific sheet on XT2000 for details.

Cutting and Dry Fitting Sheets

Avoid kinking the sheet during handling. Layout sheet location on the wall marking plumb lines and level lines where needed. When laying out the sheet allow a 1/16" gap between sheet material and ceilings, floors, corners, door casings, window casings and between sheets. Do not install cove base directly over rigid vinyl sheet. Overlap rigid vinyl sheet with the cove base by 1/4".

There will be a 1" bleed allowed on the end of each run to allow for trimming in the field. If trimming is needed, trim at the beginning and ends of a run only. Cut sheet material with a metal straight edge and a sharp utility knife using multiple passes. Cut openings in the sheet for outlets and other objects located on the wall. If corners are not plum, apply painters tape to the edge of the sheet and scribe the uneven corner of the sheet. Use a belt sander to carefully remove material from the sheet. Dry fit the sheet to the wall by holding it in place on the wall. When installing multiple sheets in an area, dry fit all sections. Do not install sheet material too close to heat registers, radiators and other equipment that may produce excessive heat. Do not remove white film from back of sheet.

Installation

To help minimize the appearance of the joint when using clear caulk, paint a 1" area behind the butt joint with a color from the applied sheet, or caulk the gap with silicone or urethane colored caulk.

If using the XT2000 adhesive, apply adhesive only to the wall surface. For more information on this application, see the enclosed attachment entitled XT2000 application instructions.

If using Spray-Lock Adhesive, see instructions attached, entitled Spray-Lock application instructions.

Wipe the back of the sheet, remove any debris. Carefully position the sheet on the wall, and allow 1/16" seam gaps. Reposition, if necessary, before rolling. Roll entire sheet with an extension roller, starting in the center and working out to the edges.

For questions, please call Olee Creative customer service at 1-800-225-5040.